

EN

Example of use

Flute with MicroCork (a) connect to the **Phantom Power Connection (b)** of a **Mixer (c)** or via **Interface (d)** to a **Computer (e)** with music-mixing software or a **Tablet (f)** with music-mixing app.

Loudspeaker (g)

Important: When using a mixer or interface, the Tomasi MicroCork **must be connected via Phantom Powering**. An external phantom power adapter is available at low cost, if the device does not provide phantom powering.

DE

Anwendungsbeispiel

Flöte mit MicroCork (a). Anschluss entweder direkt an den **Phantomspeise-Anschluß (b)** eines **Mischpults (c)** oder via **Interface (d)** an einen **Computer (e)** mit Sound-Mixer Software oder ein **Tablet (f)** mit Sound-Mixer App.

Lautsprecher (g)

Wichtig: Bei Verwendung eines Mischpults oder eines Interface **muss der Tomasi MicroCork via Phantomspeisung angeschlossen werden**. Externe Phantomspeiseadapter sind günstig erhältlich, falls das Gerät keine Phantomspeisung hat.

